



FIG. 196—TRANSFER CASE—LATE CJ-3B, CJ-5, CJ-6

1—Companion Flange  
 2—Brake Drum  
 3—Emergency Brake  
 4—Operating Lever  
 5—Oil Seal  
 6—Lever Stud  
 7—Rear Cap  
 8—Shims  
 9—Screw  
 10—Lockwasher  
 11—Bolt  
 12—Rear Cover  
 13—Gasket  
 14—Lock Plate  
 15—Transfer Case  
 16—Shift Rod  
 17—Poppet Plug  
 18—Poppet Spring  
 19—Poppet Ball  
 20—Interlock  
 21—Gasket  
 22—Front Cap  
 23—Breather  
 24—Shift Lever Spring  
 25—Shift Lever  
 25A—Shift Lever (used with 4-speed transmission)

26—Shift Lever Knob  
 27—Shift Lever  
 27A—Shift Lever (used with 4-speed transmission)  
 28—Pivot Pin  
 29—Lubrication Fitting  
 30—Set Screw  
 31—Oil Seal  
 32—Front Yoke  
 33—Gasket  
 34—Bolt  
 35—Lockwasher  
 36—Shift Rod  
 37—Shift Fork  
 38—Shift Fork  
 39—Filler Pipe Plug  
 40—Mainshaft Gear  
 41—Plain Washer  
 42—Thrust Washer  
 43—Intermediate Gear  
 44—Snap Ring  
 45—Bearing  
 46—Nut  
 47—Washer  
 48—Output Clutch Shaft  
 49—Output Clutch Gear  
 50—Snap Ring

51—Thrust Washer  
 52—Output Shaft Gear  
 53—Sliding Gear  
 54—Bushing  
 55—Output Shaft  
 56—Cone and Rollers  
 57—Bearing Cup  
 58—Speedometer Gear  
 59—Needle Bearings  
 60—Bearing Spacers  
 61—Intermediate Shaft  
 62—Drain Plug  
 63—Gasket  
 64—Nut  
 65—Bottom Cover  
 66—Sleeve  
 67—Speedometer Gear  
 68—Bushing  
 69—Gasket  
 70—Bolt  
 71—Bolt  
 72—Hex Nut  
 72—Bolt  
 73—Bolt  
 74—Lockwasher  
 75—Nut  
 76—Output Shaft Seal